DEEPCLEAN

DESCALING CLEANING AGENT

PORCELAIN TILES, CERAMIC TILES, MOSAICS, GLASS, TAPS AND CHROME-PLATED ELEMENTS



INDOOR USE

OUTDOOR USE



- **Treats all bathroom surfaces, from sanitary fittings**
- **to coverings**
- **Active foam formula: does not drip**
- **Ideal for mosaics and taps**
- **Does not affect methacrylate tubs.**
- **Does not damage stainless steel tap fittings.**
- **Cleans and deodorises, leaving a pleasant scent of white musk and mint**

WHAT IT'S FOR

- Effectively removes limescale, without leaving traces or dull marks
- Thoroughly cleans all bathroom surfaces.
- Makes everything sparklingly clean.

HOW TO USE IT

No dilution required:
ready to use.

Application: Spray **DEEPCLEAN** onto the surface to be cleaned, leave it to take effect for a few seconds then rinse it thoroughly using a damp sponge.

PACKAGING

750 ml bottles with spray nozzle in boxes of 6.

WARNINGS
• Keep out of reach of children.
• Do not disperse into the environment after use.
TEMPERATURES
Storage temperature: Between 5°C and 30°C.
The product should be applied to materials with temperature between 5° and 30°C.

Caution:
Do not use on polished marble and acid-sensitive enamel surfaces and use carefully on adjacent surfaces (avoid dripping).