

ULTRACARE KERANET EASY

Ready-to-use acid spray cleaning product that also removes cementitious residues immediately after grouting. Removes surface residues of cement, lime, and efflorescence. Suitable for cleaning the back side of porcelain tiles



BENEFITS AND FEATURES

- Quick and simple application
- Ready to use, available in spray bottle
- 1-2 minutes of waiting time before rinsing
- High performance
- Perfect when installing large-format tiles to avoid picture framing
- Can be used on the back side of tiles to remove any contamination
- Allows quick and easy removal of any residue immediately after grouting
- Can also be used the day after grouting to remove any light traces of remaining cementitious residues
- Fully offset greenhouse gases emissions

CO₂e FULLY OFFSET PRODUCTS

Residual Greenhouse Gas emissions measured throughout the life cycle of this product using Life Cycle Assessment (LCA) methodology, verified and certified with EPDs, have been offset for the year 2026 through the acquisition of carbon credits in support of forestry protection projects. For more details on emission calculations and offsetting projects, visit mapei.com.

DESCRIPTION

UltraCare Keranet Easy is used for cleaning indoor and outdoor surfaces that have been grouted using cementitious grouts and can be used on all acid resistant materials, such as porcelain, ceramic, glass mosaics, quarry tiles, terracotta and acid-resistant natural stone.

WHERE TO USE

UltraCare Keranet Easy is a simple and ready-to-use product to save time, as it can be used also immediately after grouting. It is suitable for use on porcelain, ceramic, glass mosaics, quarry tiles, terracotta, and acid-resistant natural stone. When installing large-format tiles, it is perfect for removing fresh cementitious grout residues to avoid the “frame effect”. It is also suitable for cleaning the back side of tiles prior to installation, especially with large formats.

TECHNICAL CHARACTERISTICS

UltraCare Keranet Easy is a liquid acid cleaner available in 3% aqueous solution; the product is ready to use and does not require any dilution.

Ultracare Keranet Easy is based on a special inorganic acid whose advantage is that it is as aggressive toward cement grout residues and efflorescence as much stronger acids (muriatic/hydrochloric, sulfuric, etc.) without developing the highly dangerous toxic fumes associated with the latter. In any case, use the product in well-ventilated areas.

UltraCare Keranet Easy, when properly used, will not damage the grout joint even when using coloured grouts.

RECOMMENDATIONS

- Never use **UltraCare Keranet Easy** on polished marble, limestone in general, limestone-based materials, or cementitious terrazzo tiles.
- Do not use **UltraCare Keranet Easy** on ceramic tiles or enameled baths with non-acid-resistant enamel.
- Use **UltraCare Keranet Easy** with rubber gloves and glasses, paying attention to splashes on the skin or clothes.
- Make sure before use that the surfaces to be cleaned are acid-resistant. In case of doubts, it is recommended to carry out preliminary tests.
- Do not allow the product to react for too long, and rinse thoroughly to remove all traces of the product; it could discolour the grout.
- **UltraCare Keranet Easy** does not damage metal or galvanized surfaces; however, given the variety of materials available on the market, a preliminary test is always recommended.

APPLICATION PROCEDURE

When used immediately after cementitious grouts, wait until it loses its plasticity and becomes opaque (the time required depends on the type of grouting product used), then spray **UltraCare Keranet Easy** evenly on the surface to be cleaned, leave it to react for 1-2 minutes, and then proceed with a first cleaning using a moist cellulose sponge (MAPEI sponge type), working diagonally over the grout joints. Rinse the sponge frequently using two different containers of water, one to remove the grout from the sponge and the other for rinsing the sponge.

On light cured grout residues, spray **UltraCare Keranet Easy** evenly over the entire area at a suitable distance, working in manageable areas, letting it act for a few minutes. Then wipe over the surface, removing it with the use of a moist cellulose sponge as described above.

UltraCare Keranet Easy can also be used on cured grouts with light residues; otherwise, use **UltraCare Keranet** in compliance with the indications of the specific technical data sheet.

CONSUMPTION

1 liter of **UltraCare Keranet Easy** cleans up to 10 m².

The consumption can vary depending on the amount and type of dirt and the kind of surface to be treated.

PACKAGING

UltraCare Keranet Easy is available in 750 ml bottles with spray.

STORAGE

UltraCare Keranet Easy can be stored for 4 years in its original packaging.

SAFETY INSTRUCTIONS FOR PREPARATION AND APPLICATION

Instructions for the safe use of our products can be found on the latest version of the SDS available from our website www.mapei.com.

PRODUCT FOR PROFESSIONAL USE.

TECHNICAL DATA (typical values)

PRODUCT IDENTITY

Consistency:	liquid
Colour:	transparent
Density:	1.00 g/cm ³
pH:	1.4
Recommended application temperature range:	from 0°C to +40°C
Waiting time before rinsing:	5 minutes

WARNING

Although the technical details and recommendations contained in this product data sheet correspond to the best of our knowledge and experience, all the above information must, in every case, be taken as merely indicative and subject to confirmation after long-term practical application; for this reason, anyone who intends to use the product must ensure beforehand that it is suitable for the envisaged application.

Please refer to the current version of the Technical Data Sheet, available from our website www.mapei.com

LEGAL NOTICE

The contents of this Technical Data Sheet ("TDS") may be copied into another project-related document, but the resulting document shall not supplement or replace requirements per the TDS in force at the time of the MAPEI product installation.

The most up-to-date TDS can be downloaded from our website www.mapei.com.

ANY ALTERATION TO THE WORDING OR REQUIREMENTS CONTAINED OR DERIVED FROM THIS TDS EXCLUDES THE RESPONSIBILITY OF MAPEI.

Mapei S.p.A.

Via Cafiero, 22, 20158, Milano



+39-02-376731



www.mapei.com



mapei@mapei.it

11008-7-2026 en (IT)

Any reproduction of texts, photos, and illustrations published here is prohibited and subject to prosecution

